

Manufacturer Suggested Camper Maintenance

Before Each Trip

Item	Procedure
Tires and Wheels	Check lug nuts are tightened to specified torque value. Check tire inflation pressure.
Windows and Doors	Check vinyl seals when washing exterior.
	Check seals for damage and repair as needed.
	Lubricate door hinges and step components with WD40.
	Adjust and lubricate window latches with WD40.
	Lube all door locks and strike pockets.
Water and Drainage	Check drainage systems for leaks and road damage.
Electrical System	Check GFCI circuits.
Appliances	Remove food and ice from refrigerator after each trip.
Safety Equipment	Test all detector components.
Carpeting	Vacuum after each trip.
Weight and Distribution	Keep within specified load limits.

Monthly

Item	Procedure
Fiberglass Exterior	Wash with warm water and mild detergent.
Water and Drainage	Check hoses, fittings and connections for leaks and wear.
Appliances	Clean fan blades and wash filter on range exhaust hood.
	Check for obstructions and dirt on ext. appliance vents.
Safety Equipment	Check fire extinguisher pressure and condition.
Wood Surfaces	Clean prefinished panels and wood with wood cleaner.

Every 6 Months

Item	Procedure
Fiberglass Exterior	Wax with liquid or paste wax.
Roof and Roof Components	Inspect, Wash, Treat and reseal as needed.
Axles	Torque mounting bolts to 145-150 foot pounds.
Brakes	Check operation and for uneven wear.

Yearly

Item	Procedure
Roof and Roof Components	Lubricate roof vent mechanism with light oil and clean completely.
Propane System	Have qualified service center check pressures and complete system.
Water and Drainage	Winterize system depending on local conditions.
Safety Equipment	Clean all detector components. Such as; Furnace, Water Heater, Refrigerator
Bearings	Repack wheel bearings yearly.

As Required

Item	Procedure
Propane System	Check for leaks and road damage.
Water and Drainage	Sanitize system.
Electrical System	Maintenance on generator per generator manual.
	Check and service battery/s.
Carpeting	Clean per carpet manufacturer's instructions.
Seats	Lubricate all mechanisms and inspect for proper operation.

As Required

Item	Procedure
	Check all seat belt buckles, release mechanisms and webbing.
Chassis and Components	Follow chassis lubrication and maintenance procedures.
Bearings	Repack wheel bearings yearly.
Brakes	Check operation and for uneven wear.